



TRIM IT OUT:
Use Standard
Perforated
Vinyl Soffit

Key Points:
 Top of 2x8 GMB is the same as the bottom of the furring (Dry Deck mounting plane)
 Flash all water to drop on top of the Dry Deck and/or into the gutters.

American Dry Deck

TITLE:
Section B

SIZE	DWG. NO.	REV
A	1466206	

SCALE: 1:5	SHEET 1 OF 1
------------	--------------